

INSTRUCTIONS FOR THE INSTALLATION OF DIVINA WALL ROLLS

Please read these instructions carefully in conjunction with the relevant country norms before starting the installation.

Safety Instructions

Use abrasive resistant gloves during the handling of the product. In case of using tools or cutting equipments, use gloves and goggles appropriate to the risks inherent to these operations. In case of using adhesives, use adequate breathing protection and keep out the reach of children.



Walls

1. The wall must be flat, smooth, permanently dry, firm and free of cracks, dirt and adhesion-inhibiting substances.
2. Old chalk, adhesive, oil and paint traces should be roughened with a wire brush, to obtain a substrate with absorption.
3. Waste oil must be completely removed.
4. The surface of any suitable type of substrate must be structurally sound and strong, secured, fixed, clean and free of all oil, grease, wax, dirt, varnish, lacquer, or any contaminant that can act as a bond inhibitor.
5. The irregularities should be leveled with an appropriate leveling compound.
6. Gypsum plaster, and plaster card tiles as well as other highly absorbent substrates should be primed.
7. Refer to the primer package label for dilution and drying time.